



5V	1	5V	30	3V3
GND	2	GND	29	GND
PB6	3	PA12	28	PA12
PB7	4	PA11	27	PA11
PB8	5	PA8	26	PA8
PB9	6	PA8	25	PB15
PC13	7	PB14	24	PB14
PC14	8	PB13	23	PB13
PC15	9	PB12	22	PB12
PA0	10	PB11	21	PB11
PA1	11	PB10	20	PB10
PA2	12	PB1	19	PB1
PA3	13	PB0	18	PB0
GND	14	PA7	17	PA7
3V3	15	PA6	16	PA6

Forest S1



### 电机编码器接口2



### 电机编码器接口1



### 用户按键



### 角位移传感器接口

